

<b>Contents</b>	<b>Page</b>
1 Introduction.....	1
2 Scope .....	1
3 Definitions.....	1
Part 1: Properties of acetylene.....	3
4 Properties of acetylene.....	3
4.1 Physical properties .....	3
4.2 Chemical properties.....	7
4.3 Other properties—toxicity .....	7
5 Conversion of gas volume to base conditions.....	7
Part 2: Acetylene metering (for low and medium pressure service).....	9
6 Types of meters for acetylene service.....	9
6.1 Inferential-type meters.....	9
6.2 Volumetric-type meters.....	10
7 Meter accessories .....	11
7.1 Orifice and Venturi meters.....	11
7.2 Rotary positive displacement meters.....	12
7.3 Bellows meter .....	13
8 Materials of construction for meters and accessories .....	13
8.1 Metals.....	13
8.2 Nonmetals .....	14
9 Installation of meters .....	14
9.1 Location .....	14
9.2 Installation method .....	14
9.3 Electric grounding and bonding.....	15
10 Maintenance of meters.....	15
10.1 Meter accuracy inspection.....	15
10.2 Removing the meter from service.....	15
10.3 Repairing the meter .....	15
10.4 Returning the meter to service .....	15
Part 3: Acetylene piping .....	16
11 General design .....	16
11.1 Materials.....	16
11.2 Code construction.....	16
11.3 Grounding.....	16
11.4 Weather protection .....	16
11.5 Overheating protection .....	16
11.6 Maintenance.....	16
11.7 Regulations.....	16
12 Piping .....	17
12.1 Materials.....	17
12.2 Pipe .....	17
12.3 Pipe fittings and flanges .....	17
12.4 Valves—types.....	18
12.5 Packing.....	18

12.6	Bolts and nuts for flanges .....	18
12.7	Gaskets .....	18
12.8	Pipe joint compound .....	18
12.9	Design and construction .....	18
12.10	Proximity to other facilities .....	18
12.11	Crossings .....	18
12.12	Drains .....	19
12.13	Purging facilities .....	20
12.14	Expansion joints .....	20
12.15	Corrosion prevention .....	20
12.16	Cleaning and testing .....	20
12.17	Warnings .....	20
13	Storage (gasholder).....	20
13.1	Type of equipment—gasholders.....	20
13.2	Design of equipment.....	21
13.3	Warnings .....	21
13.4	Material specifications .....	21
13.5	Location .....	21
14	Booster system.....	21
14.1	Type of equipment.....	21
14.2	Design of equipment.....	22
14.3	Controls .....	22
15	Protective devices .....	22
15.1	Types of devices.....	22
15.2	Flash arrestors.....	23
15.3	Pressure relief .....	26
15.4	Flow controls .....	28
15.5	Special valves (low and medium pressure systems only) .....	28
15.6	Emergency shutdown.....	29
15.7	Packed lines .....	29
16	General explosive behavior of acetylene .....	30
16.1	Deflagrations .....	30
16.2	Detonations .....	31
16.3	Application to design .....	37
17	References .....	38

## Tables

Table 1—Physical constants of acetylene .....	3
Table 2—Temperature versus viscosity of acetylene .....	6
Table 3—Specific heats of acetylene at 1 atm (Btu/lb × °F).....	6
Table 4—Least pressure for complete traverse of flame psia (kPa, abs) corrected to 59 °F (15.0 °C) .....	36

## Figures

Figure 1—Compressibility factors for acetylene.....	5
Figure 2—Typical liquid drain for low pressure lines.....	19
Figure 3—Typical liquid drain for medium pressure lines .....	19
Figure 4—Typical packed tower flash arrestor.....	23
Figure 5—Hydraulic backpressure valve .....	25
Figure 6—Acetylene transmission piping—typical system (low pressure production) .....	27
Figure 7—Acetylene transmission piping—typical system (medium pressure production).....	27
Figure 8—Typical flood valve (low pressure) .....	29
Figure 9—Steady rates of travel of deflagration flames through acetylene in long tubes of different diameters .....	30

Figure 10—Pressure required for deflagration and detonation of acetylene in long tubes at room temperature with nonshock thermal ignition .....	31
Figure 11—Pressure profile of reaction-zone region of ideal detonation in acetylene according to the models of (a) Zeldovich-von Neumann-Doering and (b) Cook and associates .....	32
Figure 12—Pressure profile of gas in tube (shown at top of diagram), originally containing acetylene, at an early stage (a) and a later stage (b) of travel of the detonation wave .....	33
Figure 13—Pressure profile of gas in the tube of Figure 12 shortly after the detonation front has struck the end of the tube and has given rise to reflected wave (a) and a little later (b) .....	34
Figure 14—Explosion pressure ratios developed by the cascading process in acetylene as a function of the predetonation length: tube length ratio, calculated for 40 psia (275 kPa, abs) initial pressure and applies approximately to any initial pressure .....	35
Figure 15—Predetonation distance chart for acetylene in tubes assuming nonshock thermal ignition near a closed end .....	36